

## **IRIS RL C1D2**

## **Product Installation**

## **Ceiling Mounting**






- 1.Drill four holes as above size and install expended screws(2FT fixture for 535mm.4FT for 800mm distance).
- 2.Install the light to ceiling and tighten the nuts.



3. Properly connect wires and conduit.



4.Installation complete.

## Safety caution

- 1 Power supply must be disconnected before opening the diffuser for maintenance. Scratch or damage on joint surface is strictly prohibited during maintenance.
- 2 Before use, to check whether the voltage of the power supply is consistent with that of the luminaire/lamp to avoid damage caused by the voltage discrepancy. Also, do not open the cover for live inspection.
- 3 Non-professionals are strictly prohibited for any maintenance.