


ALUME TP INSTALLATION

Installation Manual

Step1

Turn off the switch




Step2


① Drill 6mm holes on the roof/wall



② Insert 6mm expansion pipe into the hole and fix the bracket by M4 screw



Step3



Connect the wire in the outlet box.

Step4

① ceiling installation



② The final appearance



③ Tighten the screw with screwdriver




ATTENTION FRENCH

The max wattage in series can be 540W
La puissance électrique maximal en série peut être de 540W



Step5

Turn on the switch



Caution: Please note that DO NOT use this product in the following places/application

- 1.The place has a large quantity of lampblack and smoke,such as:kitchen and Food processing factory etc.
- 2.The place has a large quantity of chemical corrosive substance,such as:chemical plant and stockyard etc.
- 3.The place has poor temperature conditions,large-scale temperature variation,which would easily lead to broken and damage the product,the applicable operating temperature is between -15 and 45 degrees.

ATTENTION: à noter qu'il ne faut pas utiliser le produit dans les endroits suivants

1. Dans un lieu avec une grande quantité de fumé, par exemple: cuisine, une usine de transformation alimentaire etc.
2. Dans un endroit avec une grande quantité de substance corrosive chimique, tels qu'une: usine de produits chimiques, parc de stockage, etc.
3. Dans des lieux froids ou à variations de température à grande échelle, qui pourrait facilement emmener à casser et/ou endommager le produit. La température de fonctionnement applicable au produit est comprise entre -15 et 45 degrés.