ALUME 11G INSTALLATION


Wiring Diagram & Instruction:

- 3 dimming functions are available in this high bay light:
- 1. Constant urent can be ahieved by 0.10v Dc dmng:
- 2. PWM signal dimming;
- 3. Variation of resistance unit dimming. .

Description: This product is 0/1-10V dimming, below dimmers are recommended	
Brand	Model
LUTON	NTST V-DV
LEVI TON	DS710-10 Z / IP71 0
LEGRAN D	RH4FBL3P W

Wiring Instruction:

ACL:Black/Brown, ACN:White/Blue Green/Yellow, DIM +: Purple, DIM -: Pink, AUX:Black/White, (As for the wire color of DIM+ and DIM-. pls check the ight abel)







В

Please choose the appropriate dimming way according to your needs. You can also choose not to use this function.

*The product can not be cnneted to a dmming device when its eqipped with Motion Sensor.

. Hanging Mount: (Hook or eyebolt)

Step1. Screw the hook into the fixture, tighten and fix it. (figure 1)

Step2. Fix screws into the holes with a hammer. (Figure 4)

Step3. After installation, connect the wire of the fixture to the mains according to local wiring rules, ensure the cnnection is stable and make good potetion on the cnnecon.







